## poly-planar<sub>®</sub> MA7065 Round Speaker Installation Guide **Installation:** Find a suitable location making sure there is clearance for the Cutout and use as template for drilling installed depth. Use a hole saw or other suitable device to make a cutout. Place the speaker in the cutout and mark and drill holes for the mounting screws (supplied). If the panel is too thin or soft for screws use the stainless screw clips in the hardware kit. 7-9/16" (192mm) **Overall Diameter** Attach speaker wires supplied, solid color wire to positive (red dot or with + sign or larger tab as shown on the diagram). Please Note: Twist counter clockwise to remove the grill. When putting the grill back, twist clockwise until you hear a click. Mounting Depth 5-5/8" (144mm) 2-13/16"(71mm) **Cutout Diameter** Scale= 1:1 Reproduction may change accuracy 1352 Charwood Road • Suite D • Hanover, MD 21076 • Tel (410) 761-4000 • Fax (410) 761-6274 www.polyplanar.com