



INSTALLATION INSTRUCTIONS

IGNITE SURFACE MOUNT BACK UP LIGHT KIT

Always disconnect any power sources connected to your vehicle before servicing fuses or electrical systems. Professional installation is recommended. Note: location should be a flat vertical surface on the rear of the vehicle.

1. Mark and drill holes for install, use ¼" drill bit.
2. Install lights using provided hardware.
3. Wiring: Route cables behind bumper, trim excess, connect to factory reverse light wires. Take care to avoid any heat sources & sharp or abrasive surfaces.
4. Reconnect power source, place your vehicle in reverse and ensure lights turn on.

WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty
779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337

www.rigidindustries.com

Ignite and Rigid Industries are registered and/or common law marks owned by JST Performance, LLC, a Delaware limited liability company d/b/a Rigid Industries.