

Care and Use: 5-Piece Telescoping Professional Grill Tool Set A10-132T

USE/INSTRUCTIONS

- Never leave grill tools on or near hot surfaces
- Choose from 1 of the 3 telescoping lengths to achieve desired safe distance from the grilling surface
- To prevent possible damage to tools, collapse to shortest length for storage
- Replace grill brush bristles by removing (2) Phillips head screws. Replacement bristle (part # 12-138) available at MagmaProducts.com
- Never use metal utensils on non-stick coated surfaces


CLEANING

- Wash with warm water mild dishwashing detergent, thoroughly rinse, and air dry

WARRANTY

• Magma Products, Inc. warrants this product to be free of defects in materials and/or workmanship for a period of 1 year from the date of original purchase (proof of purchase required). • Magma Products, Inc. will not be liable for products damaged due to outside storage; discoloration from sun exposure, any weather related damages, general neglect, and/or misuse by the user. • Magma Products, Inc. must approve all product warranty claims. • Magma Products, Inc. reserves the exclusive right to repair and/or replace any product or component defective in material or workmanship during the warranty period. • Warranty claims; Do not contact or return this product to retailer. Prior to returning product contact Magma Products, Inc. directly for return authorization and instructions. • Returning warranty claims; user is responsible for all applied shipping charges.

CONTENTS:
Spatula
Fork
Grill Brush
Tongs
Storage Case




To release grill tool for extension or retraction, simply depress red button, pull or push tool to desired length, and release button in one of three convenient locking positions.

OPTIONAL GRILL TOOL ACCESSORY

Grill Tool Light (A10-144)

Attach to any Magma Telescoping Grill Tool. It attaches to any grill tool illuminating the food being grilled

- 6 Individual High-Intensity LED Light Bulbs
- Easy Use Push Button On-Off Switch
- High Temperature Silicone Cover Protect Against Smoke, Heat & Water
- Uses Long-Lasting 9 Volt Battery (Included)



MAGMA PRODUCTS, INC. • 3940 Pixie Ave. • Lakewood, CA 90712 • USA • Tel: (562) 627-0500
MagmaProducts.com • mail@MagmaProducts.com

83-132T 0817

Care and Use: 5-Piece Telescoping Professional Grill Tool Set A10-132T

USE/INSTRUCTIONS

- Never leave grill tools on or near hot surfaces
- Choose from 1 of the 3 telescoping lengths to achieve desired safe distance from the grilling surface
- To prevent possible damage to tools, collapse to shortest length for storage
- Replace grill brush bristles by removing (2) Phillips head screws. Replacement bristle (part # 12-138) available at MagmaProducts.com
- Never use metal utensils on non-stick coated surfaces


CLEANING

- Wash with warm water mild dishwashing detergent, thoroughly rinse, and air dry

WARRANTY

• Magma Products, Inc. warrants this product to be free of defects in materials and/or workmanship for a period of 1 year from the date of original purchase (proof of purchase required). • Magma Products, Inc. will not be liable for products damaged due to outside storage; discoloration from sun exposure, any weather related damages, general neglect, and/or misuse by the user. • Magma Products, Inc. must approve all product warranty claims. • Magma Products, Inc. reserves the exclusive right to repair and/or replace any product or component defective in material or workmanship during the warranty period. • Warranty claims; Do not contact or return this product to retailer. Prior to returning product contact Magma Products, Inc. directly for return authorization and instructions. • Returning warranty claims; user is responsible for all applied shipping charges.

CONTENTS:
Spatula
Fork
Grill Brush
Tongs
Storage Case




To release grill tool for extension or retraction, simply depress red button, pull or push tool to desired length, and release button in one of three convenient locking positions.

OPTIONAL GRILL TOOL ACCESSORY

Grill Tool Light (A10-144)

Attach to any Magma Telescoping Grill Tool. It attaches to any grill tool illuminating the food being grilled

- 6 Individual High-Intensity LED Light Bulbs
- Easy Use Push Button On-Off Switch
- High Temperature Silicone Cover Protect Against Smoke, Heat & Water
- Uses Long-Lasting 9 Volt Battery (Included)



MAGMA PRODUCTS, INC. • 3940 Pixie Ave. • Lakewood, CA 90712 • USA • Tel: (562) 627-0500
MagmaProducts.com • mail@MagmaProducts.com

83-132T 0817