


LABEL BACKLIGHTING:
 CONNECT TO +12 / NEG TABS FOR 12V SOURCE
 CONNECT TO +24 / NEG TABS FOR 24V SOURCE



SPARE INDICATOR LED:
 ON-INDICATING LED FOR
 FUTURE EXPANSION BREAKER.
 CONNECT BLACK LEAD TO LOAD
 SIDE OF BREAKER, CONNECT
 WHITE LEAD TO AC NEUTRAL BUS.