THE ORIGINAL

FATSAC

BALLAST BAG CO.

Barefoot International & Fly High Mfg.
3879 North Richards Street
Milwaukee, WI 53212

PHONE **414-964-3668** ▪ FAX **414-964-5767** ▪ E-MAIL **orders@fatsac.com** ▪ WEB **www.fatsac.com**

PART#	DESCRIPTION • Fittings made for automatic ballast systems
W730	FEMALE QUICK CONNECT W/CHAIN & CAP — SAC VALVE THREADS
W739	QUICK CONNECT CAP
W731	FAT SAC PLUGS — SAC VALVE THREADS
W732	FEMALE GHT — MALE QUICK CONNECT
W733-SS •	1" BARBED END — SAC VALVE THREADS — SHOULD USE PERMANENT EPOXY CEMENT (W720)
W734	MALE QUICK CONNECT — TSUNAMI PUMP THREAD
W735	FEMALE QUICK CONNECT — BLUE PERFECT UNION FITTING
W736-SS •	3/4" QUICK CONNECT — SAC VALVE THREADS — SHOULD USE PERMANENT EPOXY CEMENT (W720)
W737 •	3/4" BARBED END — SAC VALVE THREADS — SHOULD USE PERMANENT EPOXY CEMENT (W720)
W738	MALE QUICK CONNECT — 1-1/8" BARBED TSUNAMI PUMP HOSE END
W740 •	FLOW-RITE 3/4" STRAIGHT QUICK CONNECT SOCKET
W741 •	FLOW-RITE 1-1/8" STRAIGHT QUICK CONNECT SOCKET
W742 •	FLOW-RITE 3/4" ELBOW QUICK CONNECT SOCKET
W746 •	FLOW-RITE 1-1/8" ELBOW QUICK CONNECT SOCKET
W746-PLUG •	FLOW-RITE 1-1/8" PLUG FITS INSIDE W746/W741 FITTINGS TO CAP OFF PNP SYSTEMS IN BOATS — COMES WITH DOUBLE O-RINGS FOR BEST SEAL
W743-DOUBLE •	DOUBLE SIDED 1-1/8" QUICK CONNECT FITTING
W743-SS •	SUCTION STOP SAC VALVE THREADS — 1-1/8" QUICK CONNECT — SHOULD USE PERMANENT EPOXY CEMENT (W720)
W744	PRO X SERIES CHECK VALVE — ALL CHECK VALVES SLIGHTLY HINDER FLOW
W745 •	3/4" BARBED TSUNAMI PUMP FITTING
W747 •	SAC VALVE THREAD FOR TSUNAMI PUMP — SHOULD USE PERMANENT EPOXY CEMENT (W720)
W748 •	1-1/8" QUICK CONNECT TO 1" BARBED
W749	AIR RELEASE PLUG — TURN TO RELEASE AIR. FOR MANUAL FILLING, NOT FOR VENTING AUTOMATIC SYSTEMS.
W753 •	1" BARBED IN-LINE CHECK VALVE
W755 •	1-1/8" BARBED IN-LINE CHECK VALVE
W766	SUPA PUMP ZURU BALLOON ADAPTER ACCESSORY
W720	EPOXY CEMENT FOR FITTINGS, 25ML OR 1 OZ TUBES (AKA:50805) — MIX WELL BEFORE USE!

NOTE: There are many possible combinations using our Quick Connect fittings. If you are trying to accomplish something and aren't sure how to best handle it, please contact us and we will be glad to help.

IMPORTANT: Use All-Purpose PVC Cement on the threads of the W733-SS, W736-SS, W737, W743-SS, and W747 when screwing them into Fat Sacs.