



HE-EYHK

Y ADAPTER HARNESS KIT



Works in conjunction with HE-WRRK and allows two HEISE light bars, driving lights, or work lights 150 watts or less to be connected.

Instructions:

1. Attach the end of the Y adapter to the **HE-WRRK**.
2. Use the supplied extension in the **Y Adapter Harness Kit** to convert the gray connector to the green connector and plug it into the desired light (with a green connector).
3. Use the supplied extension from the **HE-WRRK** and gray to green connector to achieve previous step mentioned above.
4. **NOTE:** Each light **MUST** be 150 watts or less.



1-800-221-0932

www.HeiseLED.com

460 Walker Street, Holly Hill, FL 32117