



*Auxiliary Outboard Motor Bracket
for the following products:*

*55-0010, 55-0012, 55-0020A,
55-0021, 55-0022*

***INSTALLATION
AND
OPERATING
INSTRUCTIONS***



55-0010



55-0012 & 55-0021



55-0020A

AUXILIARY OUTBOARD MOTOR BRACKET CAUTION GUIDELINES

1. **Always** remove your motor from bracket when trailering. Failure to do so may result in damage to boat, motor, or bracket
2. Do not exceed the stated H.P. rating or weight
3. Use a safety cable when operating your motor
4. Operate motor at low speed. Avoid turning motor at full throttle. Refrain from sharp turns.
5. Operate your motor in lowest position possible for best performance
6. Always raise and tilt motor when not in use
7. Do not alter the motor mounting plate or bracket in any way.

1. The completed installation should result in the cavitation plate of the outboard motor being parallel to the surface of the water. The height of the outboard bracket on the power boat should be located so that the cavitation plate is nearly flush with the bottom of the boat immediately forward of the engine being mounted. The following instructions should be followed to achieve these results:

- Determine the distance from the outboard motors, clamp screw bracket to the cavitation plate.
- (See Diagram A) After measuring this distance (Add 12 inches).
- Attach (tape) a yardstick to the black plastic mounting board of the Panther bracket, at the previously determined distance. (See Diagram B).
- (See Diagram B) Example: the measurement from the clamp bracket to the cavitation plate of your outboard is 16 inches. After adding 12 inches, the total is 28 inches. Therefore, attach the yardstick so the 28 inch mark is even with the top of the Panther black plastic mounting board. (As per Diagram B). See Next Page.

DIAGRAM A






DIAGRAM B



2. Position the outboard motor bracket on the transom of the boat on either the starboard or port side. Care should be exercised to make sure that the bracket will not interfere with the movement of the existing engine or a rudder. The heights of the bracket should be positioned so that the end of the yardstick is flush with the bottom of the boat on powerboats or at the waterline on sailboats (See Diagram C). Have a helper mark four holes for the attachment of the bracket to the boat. The primary holes to be used are the extreme top and bottom holes on each side of the mounting bracket. In the event of obstructions on the inside of the transom, alternative holes are provided. Always use the holes the closest to the top and bottom of the bracket as possible.

DIAGRAM C



3. Check again to make sure that there are no obstructions on the inside of the transom and then drill four 3/8" holes at the marked locations. Attach the outboard bracket to the transom with the 5/16" X 3" stainless steel fasteners that are provided. For transoms that are 2" or less in thickness a backing plate should be used. When tightening the locking nuts on the attachment bolts, there should be at least two threads of the bolts protruding through the nut to insure good locking characteristics.
4. Trim adjustment should now be made to insure that the engine's cavitation plate is parallel to the bottom of the boat. While standing on either side of the boat, sight down the boat bottom and compare with the plane of the cavitation plate. If adjustment is necessary, then adjust the engine using the built-in trim adjustment, which usually consists of 3 to 5 locations. If more adjustment is needed then remove the adjustment bolt from the mounting board bracket and swivel this bracket as necessary. Be sure to reinstall the bolt in the same manner as it was removed. Do not over tighten as this will cause the bracket to bind and not move up and down smoothly. Also make sure that the nylon locking nut on this bolt has at least two threads protruding through the nut.
5. **(On Model 55-0020 only.)** On boats with reverse transoms (positive angle) it will be necessary to reverse the trim and adjustment. Remove the plastic motor plate by removing (4) bolts. Remove the adjustment bracket by removing (2) bolts on the side of the main bracket. Turn the trim and adjustment bracket 180 degrees so the (5) adjustment holes are now at the top of the bracket by the lift handle. Reattach the motor plate. The outboard bracket may now be adjusted to compensate for the reverse transom. Use any of the 5 holes to make your adjustment. Once again, make sure that the bolts that were removed for this operation are not over tightened so as to restrict the up and down movement of the bracket. **Do not** over tighten but make sure that at least two bolt threads are exposed through the locking nut.

SERVICE AND WARRANTY

Should your unit ever require service, *please do not return the product to your dealer*. Please contact our Customer Service department for special instructions on shipping and handling. Please call between 9:00 am - 3:00 pm (Central Standard Time) Monday through Friday, or send an email anytime. If service is required and covered by warranty, it will be repaired or replaced as described below. If service is required and not covered by warranty, (such as damage caused from improper trailering or from water intrusion through the breather tube), replacement parts are available for purchase and may be paid for by Visa or MasterCard.

The warranty coverage on this equipment is limited to the terms set forth below:

MarineTech Products, Inc. warrants this product to be free of defects in material and workmanship for a period of ONE (1) YEAR from the date of original retail purchase. **Positive proof of date of purchase is required for warranty service.** If service is required and covered by warranty, the unit will be repaired or replaced with new or factory rebuilt parts at no charge. The defective components must be returned to the address specified, with shipping charges prepaid. Be sure to include your name, address, telephone number and a copy of the sales receipt showing the date of original retail purchase. All sales receipts are subject to verification.

This warranty does not apply if the unit has been damaged by accident, abuse, misuse, poor installation or misapplication, or if it has been modified from its original condition, or if any serial number has been removed or defaced or altered. **This warranty does not cover any expense to remove or reinstall the unit or any of its components.** If a returned unit is not covered by warranty, the sender will be notified and given an estimate of the charges to repair or replace the unit, together with the return shipping charges.

THIS WARRANTY DOES NOT COVER SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO DAMAGE TO OR REPLACEMENT OF OTHER EQUIPMENT AND PROPERTY. THE WARRANTY AND REMEDIES SET FORTH ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. DUE TO THE SPECIAL AND UNIQUE CONDITIONS THAT MAY EXIST IN EACH APPLICATION, THE MANUFACTURER SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO DEALER, AGENT OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENSION OR ADDITION TO THIS WARRANTY.

Some states do not allow exclusion of incidental or consequential damages, so the above exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights, which may vary from state to state.

FOR SERVICE
send an email to - info@marinetechproducts.com
or call 651.486.2010

MARINETECH PRODUCTS, INC
1360 East County Road E
VADNAIS HEIGHTS, MN 55110
www.marinetechnology.com

MarineTech Products, Inc. is proud to offer these fine lines.



*SOLUTIONS FOR MOTOR MOUNTING, REMOTE STEERING, TILT & TRIM,
SHALLOW WATER ANCHORS, AND SECURITY SYSTEMS*



*THE ORIGINAL ENGINE-MOUNTED ELECTRIC TROLLING
MOTORS—HIGH THRUST WITH WHISPER QUIET EFFICIENCY*



*ROD HOLDERS, TROLLING MOTOR SUPPORTS, AND
GPS/SONAR MOUNTS*



AUXILIARY OUTBOARD MOTOR STEER SYSTEMS



THROTTLE CONTROL FOR GAS POWERED AUXILIARY MOTORS

www.marinetechproducts.com